

Clock Radio with Dual Alarm

User's Guide for Model C336 v1566-01



FCC WARNINGS

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ADDITIONAL WARNINGS AND PRECAUTIONS

- **CAUTION:** TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.
- Mains plug is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the apparatus from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.

- Caution marking is located at the rear or bottom of the apparatus.
- **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain, moisture, dripping, or splashing.
- **CAUTION:** Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.
- **WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- **WARNING:** Do not place this unit directly onto furniture surfaces with any type of soft, porous, or sensitive finish. As with any rubber compound made with oils, the feet could cause marks or staining where the feet reside. We recommend using a protective barrier such as a cloth or a piece of glass between the unit and the surface to reduce the risk of damage and/or staining.
- **CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- **WARNING:** Shock hazard - Do Not Open.
- Battery shall not be exposed to excessive heat such as sunshine, fire or the like.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.
- **WARNING:** DO NOT INGEST BATTERY, CHEMICAL BURN HAZARD. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Do not mix old and new batteries.
- Completely replace all old batteries with new ones.
- Batteries should be recycled or disposed of as per state and local guidelines.
- **WARNING:** This product may contain chemicals known to the State of California to cause birth defects, or other reproductive harm (California Prop 65). Wash hands after handling.
- This product meets and complies with all Federal regulations.

Orientation

Features

- 1.8" green LED display with digital clock
- Dual alarm
- Wake to alarm or radio
- Sleep timer
- Snooze
- Digital AM/FM radio (PLL) with built-in antennas
- Radio station presets (10 FM/10 AM)
- Built-In speaker
- Digital volume control
- Aux in (3.5mm audio input)
- AC power: built-in AC power adapter
- Battery backup: requires 2 AAA batteries for clock and last user settings

Tuning/Min/Hour

Press to tune the radio.
Press to adjust the minute or hour when setting the clock or alarm.

Clock/Mem

In Off mode, press and hold to begin setting the time.
In radio mode, press to cycle through preset stations.

Dimmer

Press to dim the display.

Volume/ALM2/ALM1

Press to adjust the volume.
Press and hold to begin setting Alarm 1 or Alarm 2.

Snooze/Sleep

Press to snooze the alarm after it sounds.
Press repeatedly to set the sleep timer.

Power/Source/ALM Off

Press to turn the unit on.
Press and hold to turn off the radio.
Press to turn off the alarm.
Press repeatedly to select AM, FM or Aux.

LED Display

PM Indicator

Lights when the time is in the PM.

Alarm 1: Buzzer/Radio Indicator


Indicates alarm 1 is set to buzzer or radio.

Sleep Indicator

Lights when the Sleep Timer is ON.


Alarm 2: Buzzer/Radio Indicator

Indicates alarm 2 is set to buzzer or radio.




Power & Battery

To power the unit, plug the power cord on the back of the unit into a standard AC power outlet.



Requires 2 AAA batteries (not included). Batteries are used to power the clock and save user settings if no AC power is present.



Clock & Sleep Timer

Setting the Clock

1. If in radio mode, press and hold the **Power/Source/ALM OFF** button to turn the unit off.
2. Press and hold the **Clock/Mem** button until the display begins to blink, then release the button.
3. Press the **Hour** button to set the hour. *The PM indicator will light when the hour is set in the PM.*
4. Press the **Min** button to set minutes.
5. Press the **Clock/Mem** button to finish setting the time.

Setting the Sleep Timer

1. Press the **Snooze/Sleep** button repeatedly to set the sleep timer (90, 80, 70, 60, 50, 40, 30, 20, 10 min or OFF).
2. Once the set sleep time has expired the clock radio will automatically power off.

Alarm

Setting the Alarm

1. If in radio mode, press and hold the **Power/Source/ALM OFF** button to turn the unit off.
2. Press and hold the **ALM1 or ALM2** button until the display begins to blink.
3. Press the **Hour** button to set the hour. *The PM indicator will light when the hour is set in the PM.*
4. Press the **Min** button to set the minutes.
5. Press the **ALM1 or ALM2** buttons repeatedly to select Radio, Buzzer, or Alarm OFF.
6. Once the set alarm time is reached, the alarm will sound.
7. To set the other alarm, follow the above steps and choose the alarm not currently set.

Disabling the Alarm

1. Press the **ALM1 or ALM2** buttons until the indicator is no longer lit.

Snooze and Alarm Reset

After the alarm sounds:

Press the **Snooze/Sleep** button to delay the alarm for an additional 9 minutes.

OR

Press the **Power/Source/ALM OFF** button to turn the alarm off until the set alarm time is reached again.

Radio

An AM/FM antenna is built into the clock radio. To improve radio reception, adjust the position of the clock radio.

Tuning the AM or FM Radio

1. Press the **Power/Source/ALM OFF** button to turn the clock radio on.
2. Press the **Power/Source/ALM OFF** button again to select AM, FM or Aux In.
3. Press the **Tun+/-** buttons to adjust the radio to the desired frequency.
4. Press and hold the **Tun +/-** buttons to search for the next available frequency.
5. Press the **Vol+/-** buttons to adjust the volume.
6. Press and hold the **Power/Source/Al Off** to turn the radio off.


Saving Radio Presets

1. Tune to the desired station.
2. Press and hold the **Clock/Mem** button to save the current radio station as a preset.
3. Press the **Tun +/-** buttons to select the preset (P01-P10) to be saved.
4. Press the **Clock/Mem** button to cycle through radio presets.

Aux In

Requires a 3.5 mm audio input cable (not included).

1. Plug a 3.5 mm audio input cable into the **Aux In** input on the rear of the unit and an audio output/headphone jack on an MP3 Player or phone.
2. Press the **Power/Source/Al Off** button to power ON the clock radio.
3. Press the **Power/Source/Al Off** to set the source to **Aux**.
4. Audio played through the connected device should now be heard through the speakers.



International Support

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: www.iLiveElectronics.com

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en: www.iLiveElectronics.com

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur: www.iLiveElectronics.com

For Warranty Information and the most up-to-date version of this User's Guide, go to www.iLiveElectronics.com

Customer Service: 1-888-999-4215 | **Email Support:** prodinfo@dpiinc.com | **Email Parts:** partsinfo@dpiinc.com

Copyright © 2016 Digital Products International (DPI, Inc.) All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.

